

## PK-232 Operation

### MORSE

K		Preload transmit buffer.
	^C	Go to Command Mode.
TC		Clear transmit buffer.
X		Go to transmit.
	=	$\overline{BT}$ - Break, pause.
	&	$\overline{AS}$ - Wait.
	+	$\overline{AR}$ - End of message.
	*	$\overline{SK}$ - End of QSO.
	^D	Go to receive + go to Command Mode.
	^C	Go to Command Mode (stay in Xmit).
R		Go to receive + receive speed unlocked and set to transmit speed.
Useful settings:		
MSP		Read current transmit speed.
MSP nn		Set transmit speed (5-99 wpm).
L		Lock receive speed.
MO		Unlock receive speed.

---

### BAUDOT

K		Preload transmit buffer.
	^C	Go to Command Mode.
TC		Clear transmit buffer.
X		Go to transmit.
	^D	Go to receive + go to Command Mode.
	^C	Return to Command Mode (stay in Xmit).
L		Force LETTERS.
R		Go to receive.
Useful settings:		
RXR xx		Receiver mark-space reverse (off,on)
AAB txt		Set AnswerBack text (21 chars max, last char not sent).
WRU xx		Set WRU (off,on) to respond to "\$"
RB R		Read current baud rate.
RB nn		Set baud rate (45,50,57,75,100,U,D)